




See online  
technical sheet

## / LW11-71 Torque wrench

### / Standards



- IEC 60832-2



### / Use

The torque wrench is used to tighten the screws or nuts on the terminal blocks to their required torque. An acoustic signal indicates that the desired torque has been reached. Orange-coloured insulating rod. Universal bit and socket holder for sockets of the 12.7 mm (1/2 inch) series, made of corrosion-resistant metal. Synthetic body, with torque display, and carrying a 9 V battery powered sound device inside.

### / Areas of activity

-  Electrical distribution
-  Transport

### / Technical specifications

- **Dimensions (mm)** : 700x150x60mm
- **Pole kind** : Pole accessories
- **Operating voltage (V)** : HTB (> 50 000 V)
- **Pole adaptators** : Universal (U)
- **Accessory weight (kg)** : 0,8
- **Overall dimensions (Inch)** : 27,6x5,9x2,4 in.
- **Accessory weights (lbs)** : 1,76